




# Proportional Actuation of WisperValve 6724

Hünenberg, 12. Noember 2020

**bürkert**  
FLUID CONTROL SYSTEMS

# Proportional Actuation of WhisperValve 6724



The new and unique electrodynamic actuator allows


- Fast and **proportional** movement
- High lifecycle
- No noise creation from the hitting of the moving and fixed parts
- Low power consumption at 100% duty cycle

# Proportional Actuation of WhisperValve 6724 status quo

## Measurement result: Flow characteristic curve

flow direction below seat 1 bar

Control voltage 0-5 V corresponds to device voltage 0-24 V




# Proportional Actuation of WhisperValve 6724


## Status quo

### Measurement results:


results		comments
Usable voltage range in which the flow rate changes	About 2,1V	at Kv-value 0,026m <sup>3</sup> /h ( $\triangleq$ 11,5 lN/min flow rate)
Valve opening / valve closing Maximum valve opening	about 9 – 10V About 12V	Basic condition: 24V
Preferred flow direction	Below seat	
Back pressure	sensitive	Hysteresis increases




# Differences in work principle: Classic prop. valve vs. whisper valve




# Characteristics 6724 compared to 2871



# Characteristics 6724 compared to 2871




# Characteristics 6724 compared to 2871



Smaller adjusting range




# Characteristics 6724 compared to 2871



# Characteristics 6724 compared to 2871

## Temperature influence (EPDM)



# application example 1: proportional valve in a Mass Flow Controller MFC


**Measurement of settling time  $t_{95\%}$  at step wise change of the set-point:**

**10%, 90%, 10% (1, 9, 1 lN/min)**

Flow direction 1 bar over seat

valve  
position  
in %

Flow rate  
in lN/min



"Overshoot"  
Control parameters not  
adapted to the valve, settings  
for Type 6724 too dynamic

→ Control parameters need  
to be adapted

Further measurements of other set points:  
for example: 0%,100%,0% ... 50%,51%,50% ... 50%,50,25%,50%

## Type 6724 possible applications

- Valve is very suitable for a closed control loop
- The biggest advantage of the valve is the separation of the media.
- The valve is suitable for special applications as the pressure range and the selection of nominal sizes are limited.
- The valve is less dynamic than classic proportional valves.
- It is insensitive to vibration as the separating diaphragm acts as a vibration damper.



# Vielen Dank!

Bürkert Fluid Control Systems  
Christian-Bürkert-Straße 13-17  
74653 Ingelfingen  
Deutschland

Tel.: +49 (0) 7940/10-0  
Fax: +49 (0) 7940/10-91 204  
[info@buerkert.de](mailto:info@buerkert.de)  
[www.buerkert.de](http://www.buerkert.de)

**We make ideas flow.**

**bürkert**  
FLUID CONTROL SYSTEMS